



Installation of Softbed Standard (top cover fixed at both sides)

These mattress systems consist of polylatex foam under pads 63 x 39 x 1.25 inches and endless rubber top cover 72 inches wide and .16 inches thick.

Only top covers 4GS and 8GS are suited for the installation as described hereafter.

1) The latex foam pads are laid on the concrete with 4-inch distance to the concrete edge (alley). The entire run of latex should be wrapped in plastic.

2) Top cover is unrolled on top of the 63-inch-wide latex pads. The top cover exceeds the latex by 4 inches on both sides of the latex pads. (top cover should remain unrolled flat before fixing)

3) Fasten the cover with 2.5-inch x ¼ inch stainless anchors with washers on the back side (alley) of the mat. The fixings are positioned every 12 inches on the back side of the top cover

4) Fasten the cover every 10 inches along the brisket side of the cover and the ends using the black plastic strips and the 2.5-inch anchors.

Important: Fixings must be positioned with 2 inches distance to the edge of the rubber in order to obtain a flat and even seal of the rubber top cover.